

How to activate Call Waiting and Forwarding facilities to Citylink CDMA phone?

Call Waiting

- Activation : * 700 + Press "Call" button
- De-Activation : * 740 + Press "Call" button

Call Forwarding

- All (Unconditional) Activation : * 72 (Phone Number 10digits) # + Press "Call" button
- All (Unconditional) De-activation : * 720 + Press "Call" button
- No Answer
 - Activation : * 71 (Phone Number 10digits) # + Press "Call" button
 - De-activation : * 713 + Press "Call" button
- Busy
 - Activation : * 74 (Phone Number 10digits) # + Press "Call" button
 - De-activation : * 743 + Press "Call" button

Activation through Citylink CDMA phones/Terminals.

AIJI - Not Applicable.

ZTE

Call Waiting

- Menu →Settings →Subservices→ OK→ Call Waiting→ Active → OK.
- Menu →Settings → Subservices→ OK→ Call Waiting→ De-active → OK.

Call Forwarding

- All : Menu →Settings →Subservices→ OK→ Call forwarding →OK
- Busy } Activate→ OK→ Give Number to Forward→ OK
- No answer }

HUAWEI

Call Waiting

- Menu → Settings → Call Settings → Call Waiting → Activate
- Menu → Settings → Call Settings → Call Waiting → Deactivate

Call Forwarding

- All : Menu → Settings → Call Settings → Call Forwarding → All → Deactivate
 - Busy
 - No answer
- } Menu → Settings → Call Settings → Call Forwarding → All → Activate → Forwarded To (enter tel No)